
BENDING LOSS IN OPTICAL FIBERS


ACTIVITY 1

<u>AIM</u>: To determine the attenuation constant of the given optical fiber.

APPARATUS: Optical fibers of length 1m & 100m, Laser source, small solar panel, Screen

TABULAR COLUMN:





FORMULA USED:

The attenuation constant is obtained from $\alpha = \frac{10}{L_1 - L_2} \log_{10} \frac{P_{\text{output}}}{P_{\text{input}}} \ dB/km$

RESULT: The attenuation constant is found to bedB/km

Note:

- 1. This exercise maybe repeated for optical fibers of different length.
- 2. Replace solar panel with LDR. Find the attenuation constant.