
Damping coefficient for Simple Harmonic Oscillator

<u>Aim</u>: To determine Damping Coefficient of Simple Harmonic Oscillator.

Apparatus: Spring, Simple Harmonic Oscillator, stop clock, Damping apparatus

Introduction: In a damped harmonic oscillator, the amplitude decreases gradually due to losses such as friction, impedance etc. The oscillations of a mass kept in water, charge oscillations in a LCR circuit are examples of damped oscillations. Let us assume that in addition to the elastic force F = -kx, there is a force that is opposed to the velocity, F = b v where b is a constant known as resistive coefficient and it depends on the medium, shape of the body.



Mass (a magnet) is placed in a cylindrical Solenoid of 500 turns (22 gauge). The emfinduced in the coil opposes the oscillations and provides velocity dependent damping.

For the oscillating mass in a medium with resistive coefficient b, the equation of motion is given by

$$m\frac{d^2x}{dt^2} + kx + b\frac{dx}{dt} = 0$$

This is a homogeneous, linear differential equation of second order.

The auxiliary equation is $D^2 + \frac{b}{m}D + \frac{k}{m} = 0$

The roots are $D_1 = -\frac{b}{2m} + \frac{1}{2m} \sqrt{b^2 - 4mk}$ and $D_2 = -\frac{b}{2m} - \frac{1}{2m} \sqrt{b^2 - 4mk}$

The solution can be derived as $x(t) = Ce^{-\left(\frac{b}{2m} - \frac{1}{2m}\sqrt{b^2 - 4mk}\right)t} + De^{-\left(\frac{b}{2m} + \frac{1}{2m}\sqrt{b^2 - 4mk}\right)t}$

Note: This can be expressed as $x(t) = Ae^{-\frac{b}{2m}t} \cos(\omega t - \phi)$ where $\omega = \sqrt{\frac{k}{m} - \left(\frac{b}{2m}\right)^2}$

$$A = \sqrt{C^2 + D^2} \qquad \phi = \tan^{-1}(D/C)$$

Here, the term $Ae^{-\frac{b}{2m}t}$ represents the decreasing amplitude and $(\omega t - \phi)$ represents phase

Procedure:

- 1. Set the mass in to SHM and find its amplitude A.
- 2. Connect the two ends of the cylindrical solenoid to set up the damping by the process of Lenz's law.
- 3. Measure the time taken for amplitude A to decrease to $\,A_{1/2}$ and calculate damping coefficient by the formula

$$b = \frac{2m \cdot \ln 2}{t_{\frac{1}{2}}}$$

OBSERVATIONS:

Mass of the oscillator =kg

Trial no	Amplitude A (cm)	A/2	Time taken for amplitude A to
			decrease to A/2
1			
2			
3			

Formula:

$$x = Ae^{-\frac{b}{2m}t}$$

$$at \ t = t_{\frac{1}{2}}$$

$$\frac{A}{2} = Ae^{-\frac{b}{2m}t_{\frac{1}{2}}}$$

$$b = \frac{2m \cdot \ln 2}{t_{\frac{1}{2}}}$$

Result: The damping coefficient is found to bekg/s